



WAE-WYE SERIES SINGLE SPLIT DC INVERTER

AIR CONDITIONER / HEAT PUMP SYSTEMS

SERVICE MANUAL

Mono DC



Revision A: 1312030001, Content updated.

Parker Davis HVAC International, Inc.
2260 NW 102nd Place, Doral, FL 33172
Ph: (305) 513-4488 info@pd-hvac.com

Cooling Only Model Numbers (Indoor + Outdoor Units):

- WAE009AMFI15RL (WE009AMFI15CLD + AN009AMFI15RPD)
- WAE012AMFI15RL (WE012AMFI15CLD + AN012AMFI15RPD)
- WAE012GMFI15RL (WE012GMFI15CLD + AN012GMFI15RPD)
- WAE018GMFI15RL (WE018GMFI15CLD + AN018GMFI15RPD)
- WAE024GMFI15RL (WE024GMFI15CLD + AN024GMFI15RPD)

Heat Pump Model Numbers (Indoor + Outdoor Units):

- WYE009AMFI15RL (WE009AMFI15HLD + YN009AMFI15RPD)
- WYE009GMFI15RL (WE009GMFI15HLD + YN009GMFI15RPD)
- WYE012AMFI15RL (WE012AMFI15HLD + YN012AMFI15RPD)
- WYE012GMFI15RL (WE012GMFI15HLD + YN012GMFI15RPD)
- WYE018GMFI15RL (WE018GMFI15HLD + YN018GMFI15RPD)
- WYE024GMFI15RL (WE024GMFI15HLD + YN024GMFI15RPD)

Table of Contents

1. Precaution
2. Part Names And Functions
3. Specification
4. Dimension
5. Refrigerant Cycle Diagram
6. Wiring Diagram
7. Installation Details
8. Operation Characteristics
9. Electronic Function
10. Troubleshooting
11. Exploded View
12. Disassembly Instructions



WARNING

- Installation MUST conform with local building codes or, in the absence of local codes, with the National Electrical Code NFPA70/ANSI C1-1993 or current edition and Canadian Electrical Code Part1 CSA C.22.1.
- The information contained in the manual is intended for use by a qualified service technician familiar with safety procedures and equipped with the proper tools and test instruments.
- Installation or repairs made by unqualified persons can result in hazards to you and others.
- Failure to carefully read and follow all instructions in this manual can result in equipment malfunction, property damage, personal injury and/or death.



- This service manual is only for service engineers to use

CONTENTS

1. Precaution	1
1.1 Safety Precaution	1
1.2 Warning	1
2. Part Names And Functions	4
2.1 Model Names of Indoor/Outdoor units	4
2.2 Part names of Indoor/Outdoor units	5
2.3 Functions of Indoor/Outdoor units	6
3. Dimension	8
3.1 Indoor Unit	8
4.2 Outdoor Unit	10
4. Refrigerant Cycle Diagram	12
5. Wiring Diagram	14
5.1 Indoor Unit	14
5.2 Outdoor Unit	17
6 Installation Details	21
6.2 Connecting the cables	21
6.3 Pipe length and the elevation	21
6.4 Installation for the first time	23
7.5 Adding the refrigerant after running the system for many years	24
7.6 Re-installation while the indoor unit need to be repaired	24
7.7 Re-installation while the outdoor unit need to be repaired	25
7. Operation Characteristics	27
8. Electronic Function	28
8.1 Abbreviation	28
8.2 Display function	28
8.3 Main Protection	29
8.4 Operation Modes and Functions	30
9. Troubleshooting	36
9.1 Indoor Unit Error Display	37
9.2 Outdoor unit error display	38
9.3 Diagnosis and Solution	42
10. Exploded View	63
10.1 Indoor unit	Error! Bookmark not defined.
11.2 Outdoor unit	Error! Bookmark not defined.

1. Precaution

1.1 Safety Precaution

- To prevent injury to the user or other people and property damage, the following instructions must be observed carefully.
- Incorrect operation due to ignoring instructions will cause harm or damage.
- Before servicing the unit, be sure to read this service manual entirely.

1.2 Warning

➤ Installation

- Do not use a defective or underrated circuit breaker. Use this appliance on a dedicated circuit.

There is risk of fire or electric shock.

- For electrical work, contact the dealer, seller, a qualified electrician, or an authorized service center.

Do not disassemble or repair the product, there is risk of fire or electric shock.

- Always ground the product.

There is risk of fire or electric shock.

- Install the panel and the cover of control box securely.

There is risk of fire or electric shock.

- Always install a dedicated circuit and properly rated breaker.

Improper wiring or installation may cause electric shock.

- Use the correctly rated breaker or fuse.

There is risk of fire or electric shock.

- Do not modify or extend the power cable.

There is risk of fire or electric shock.

- Do not install, remove or reinstall the unit by yourself (End User).

There is risk of fire, electric shock, explosion, or injury.

- Be cautious when unpacking and installing the product.

Sharp edges could cause injury, be especially careful of the case edges and the fins on the condenser and evaporator.

- For installation, always contact the dealer or an authorized service center.

- Do not install the product on weak or defective structures or stands.

- Be sure the installation area does not deteriorate with age.

If the base collapses, the air conditioner could fall with it, causing property damage, product failure, and personal injury.

- Do not let the air conditioner run for a long time when the humidity is very high and a door or a window is left open.

- Take care to ensure that power cable could not be pulled out or damaged during operation.

There is risk of fire or electric shock.

- Do not place anything on the power cable.

There is risk of fire or electric shock.

- Do not plug or unplug the power supply during operation.

There is risk of fire or electric shock.

- Do not touch the product with wet hands during operation.

- Do not place a heater or other appliance near the power cable.

There is risk of fire and electric shock.

- Do not allow water to run into electrical parts.

It may cause fire, failure of the product, or electric shock.

- Do not store or use flammable gas or combustibles near the product.

There is risk of fire or failure of product.

- Do not use the product in a tightly closed space for a long time.

Oxygen deficiency could occur.

- When flammable gas leaks, turn off the gas and open a window for ventilation before turning the product on.

- If strange sounds or smoke comes from product, turn the breaker off or disconnect the power supply cable.

There is risk of electric shock or fire.

■ **Stop operation and disconnect the power during storm or hurricane. If possible, further secure the product before the hurricane arrives.**

There is risk of property damage, failure of product, or electric shock.

■ **Do not open the inlet grill of the product during operation. (Do not touch the electrostatic filter, if the unit is so equipped.)**

There is risk of physical injury, electric shock, or product failure.

■ **If the indoor section gets wet, contact an authorized service center.**

There is risk of fire or electric shock.

■ **Be cautious that water should not enter the product.**

There is risk of fire, electric shock, or product damage.

■ **Ventilate the product from time to time when operating it together with a nearby stove etc.**

There is risk of fire or electric shock.

■ **Turn the main power off when cleaning or maintaining the product.**

There is risk of electric shock.

■ **When the product will not be used for a long time, disconnect the power supply by turning off the breaker.**

There is risk of product damage or failure, or unintended operation.

■ **Take care to ensure that nobody could step on or fall onto the outdoor unit.**

This could result in personal injury and product damage.

➤ CAUTION

■ **Always check several times for refrigerant leakage after installation or repairing the product.**

Low refrigerant levels may cause failure of product.

■ **Install the drain hose to ensure that water is drained away properly.**

A bad connection may cause water leakage.

■ **Keep perfect level when installing the**

product.

To avoid vibration of water leakage.

■ **Do not install the product where the noise or hot air from the outdoor unit could disturb the neighbors.**

It may cause disturbance for your neighbors.

■ **Use two or more people to lift and transport the product.**

■ **Do not install the product where it will be exposed to sea wind (salt spray) directly.**

It may cause corrosion on the product.

Corrosion, particularly on the condenser and evaporator fins, could cause product malfunction or inefficient operation.

➤ Operational

■ **Do not expose the skin directly to cool air for long time. (Do not sit in the path of the air draft).**

■ **Do not use the product for special purposes, such as preserving foods, works of art etc. It is a consumer air conditioner, not a precision refrigeration system.**

There is risk of damage or loss of property.

■ **Do not block the inlet or outlet of air flow.**

■ **Use a soft cloth to clean. Do not use harsh detergents, solvents, etc.**

There is risk of fire, electric shock, or damage to the plastic parts of the product.

■ **Do not touch the metal parts of the product when removing the air filter. They are very sharp.**

■ **Do not step on or put anything on the product. (outdoor unit)**

■ **Always insert the filter securely.**

Clean the filter every two weeks or more often if necessary.

A dirty filter reduces the efficiency of the air conditioner and could cause product malfunction or damage.

■ **Do not insert hands or other objects through air inlet or outlet while the product is operating.**

■ **Do not drink the condensate water drained from the product.**

■ **Use a firm stool or ladder when cleaning or maintaining the product.**

Be careful and avoid personal injury.

■ **Replace the all batteries in the remote control with new ones of the same type. Do not mix old and new batteries or different types of batteries.**

There is risk of fire or explosion.

■ **Do not recharge or disassemble the batteries. Do not dispose of batteries in a fire.**

They may burn or explode.


■ **If the liquid from the batteries gets onto your skin or clothes, wash it well with clean water. Do not use the remote if the batteries have leaked.**

2. Part Names And Functions

2.1 Model Names of Indoor/Outdoor units

Series	Capacity	Indoor units	Outdoor units
Inverter	9k	WE009AMFI15CLD	AN009AMFI15RPD
		WE009AMFI15HLD	YN009AMFI15RPD
		WE009GMFI15HLD	YN009GMFI15RPD
	12k	WE012AMFI15CLD	AN012AMFI15RPD
		WE012AMFI15HLD	YN012AMFI15RPD
		WE012GMFI15CLD	AN012GMFI15RPD
		WE012GMFI15HLD	YN012GMFI15RPD
	18k	WE018GMFI15CLD	AN018GMFI15RPD
		WE018GMFI15HLD	YN018GMFI15RPD
	24k	WE024GMFI15CLD	AN024GMFI15RPD
		WE024GMFI15HLD	YN024GMFI15RPD

2.2 Part names of Indoor/Outdoor units



Names of parts


Indoor unit

1. Front panel
2. Air inlet
3. Air filter
4. Air outlet
5. Horizontal air flow grille
6. Vertical air flow louver(inside)
7. Display panel

Outdoor unit

8. Connecting pipe
9. Connecting cable
10. Stop valve

2.3 Functions of Indoor/Outdoor units



O: optional function

- Cold Catalyst Filter:

Eliminate formaldehyde and other volatile organic compounds as well as harmful gases and odors.

- Ionizer:

Release negative ions, eliminate odor, dust, smoke and pollen particles to give you fresh and healthy air.

- Silver Ion Filter:

Sterilize bacteria effectively by decomposing cell wall of bacteria.

- Vitamin C Filter:

Release Vitamin C which can eliminate active oxygen to beautify the skin.

- 3M HAM Filter:

Open-hole-structure with charged electrostatic effectively capture dust and particles, ensure maximum air flow and minimum pressure drop.

- Bio Filter(O):

Bio filter consists of a specialized biological enzyme and Eco filter. The Eco filter catches very small airborne dust particles and bacteria, fungi and microbes. Biological enzyme kills bacteria by dissolving their cell wall thus eliminating the problem of re-pollution.

- Golden Fin:

The Golden hydrophilic condenser can improve the heating efficiency by accelerating the defrosting process. The unique anticorrosive golden coating on the condenser can withstand the salty air, rain and other corrosive elements.

- Self Clean:

When this function is activated, firstly the indoor unit operates as Fan-only mode with low fan speed, during this period the condensed water will take some dust on evaporator fins away. After that the unit turns to heating operation with low fan speed which dries the inside of indoor unit. Finally it turns to fan-only mode and blows away the wet air. The whole process cleans the internal side of indoor unit and prevents the breeding of bacteria.

- Follow me:

With this technology, a temperature sensor is built in the remote control when you stay close to the remote control, the unit will automatically change the operation mode to supply comfortable temperature just like the air conditioner is following you.

- Louver position memory function:

When starting the unit again after shutting down, its louver will restore to the angle originally set by the user

- Refrigerant leakage detect:

The refrigerant leakage detect function can better prevent the compressor being damaged by refrigerant leakage or compressor overload.

- Self-diag.Function:

Monitoring some abnormal operations or parts failures, microcomputer of the air conditioner will switch off and protect the system automatically. Meanwhile, the error or protection code will be displayed on the indoor unit.

- PTC heating belt:


With a PTC heating belt fitted on the base plate of the outdoor unit, the rain, snow or defrosted water accumulating on the base plate is avoided.

- Compressor crankcase heater:


The oil dissolves easily in refrigerant, especially in low temperature condition. The crankcase heating belt can heat the bottom of the compressor to avoid pumping out too much oil with the refrigerant, which helps to protect the compressor.

3. Dimension


3.1 Indoor Unit



Model	W	D	H
WE009AMFI15CLD	680mm (26.8in)	178mm (7.0in)	255mm (10.0in)
WE009AMFI15HLD			
WE009GMFI15HLD			
WE012AMFI15CLD	770mm (30.3in)	188mm (7.4in)	255mm (10.0in)
WE012AMFI15HLD			
WE012GMFI15CLD			
WE012GMFI15HLD			
WE018GMFI15CLD	905mm (35.6in)	198mm (7.8in)	275mm (10.8in)
WE018GMFI15HLD			
WE024GMFI15CLD	1030mm (40.6in)	218mm (8.6in)	315mm (12.4in)
WE024GMFI15HLD			






Model	R	L	H	Dimension of installation hole
WE009AMFI15CLD	92mm (3.6in)	170mm (6.7in)	45mm (1.8in)	Φ65mm(2.56in)
WE009AMFI15HLD				
WE009GMFI15HLD				
WE012AMFI15CLD	95mm (3.7in)	170mm (6.7in)	45mm (1.8in)	
WE012AMFI15HLD				
WE012GMFI15CLD				
WE012GMFI15HLD	80mm (3.1in)	100mm (3.9in)	45mm (1.8in)	
WE018GMFI15CLD				
WE018GMFI15HLD				



Model	R	L	H	Dimension of installation hole
WE024GMFI15CLD	163mm (6.4in)	293mm (11.5in)	45mm (1.8in)	Φ65mm(2.56in)
WE024GMFI15HLD				

4.2 Outdoor Unit




Note: The above drawing is only for reference. The appearance of your units may be different.

Model	W	H	D	W1	A	B
YN009GMFI15RPD	700mm (27.6in)	240mm (9.4in)	540mm (21.3in)	757mm (29.8in)	458mm (18.0in)	250mm (9.8in)
AN009AMFI15RPD	660mm (26.0in)	265mm (10.4in)	540mm (21.3in)	732mm (28.8in)	458mm (18.0in)	276mm (10.9in)
YN009AMFI15RPD	660mm (26.0in)	265mm (10.4in)	540mm (21.3in)	732mm (28.8in)	458mm (18.0in)	276mm (10.9in)
YN012AMFI15RPD	660mm (26.0in)	265mm (10.4in)	540mm (21.3in)	732mm (28.8in)	458mm (18.0in)	276mm (10.9in)


AN012AMFI15RPD	660mm (26.0in)	265mm (10.4in)	540mm (21.3in)	732mm (28.8in)	458mm (18.0in)	276mm (10.9in)
YN012GMFI15RPD	780mm (30.7in)	250mm (9.8in)	540mm (21.3in)	843mm (33.2in)	549mm (21.6in)	276mm (10.9in)
AN012GMFI15RPD	780mm (30.7in)	250mm (9.8in)	540mm (21.3in)	843mm (33.2in)	549mm (21.6in)	276mm (10.9in)
AN018GMFI15RPD	760mm (29.9in)	285mm (11.2in)	590mm (23.2in)	823mm (32.4in)	530mm (20.9in)	290mm (11.4in)
YN018GMFI15RPD	760mm (29.9in)	285mm (11.2in)	590mm (23.2in)	823mm (32.4in)	530mm (20.9in)	290mm (11.4in)
AN024GMFI15RPD	845mm (33.3in)	320mm (12.6in)	700mm (27.6in)	908mm (35.7in)	560mm (22.0in)	335mm (13.2in)
YN024GMFI15RPD	845mm (33.3in)	320mm (12.6in)	700mm (27.6in)	908mm (35.7in)	560mm (22.0in)	335mm (13.2in)

4. Refrigerant Cycle Diagram

For cooling only models:




For heat pump models:



5. Wiring Diagram


5.1 Indoor Unit

9000 BTU, 230V, Heat Pump / 12000 BTU, 230V, Cool Only / 12000 BTU, 230V, Heat Pump




9000 BTU, 115V, Cool Only / 9000 BTU, 115V, Heat Pump


12000 BTU, 115V, Cool Only / 12000 BTU, 115V, Heat Pump




18000 BTU, 230V, Cool Only / 18000 BTU, 230V, Heat Pump




24000 BTU, 230V, Cool Only / 24000 BTU, 230V, Heat Pump




18000 BTU, 230V, Cool Only / 18000 BTU, 230V, Heat Pump




24000 BTU, 230V, Cool Only / 24000 BTU, 230V, Heat Pump




For 9000 BTU, 230V, Heat Pump / 12000 BTU, 230V, Cool Only / 12000 BTU, 230V, Heat Pump:




For 9000 BTU, 115V, Cool Only / 9000 BTU, 115V, Heat Pump / 12000 BTU, 115V, Cool Only / 12000 BTU, 115V, Heat Pump:



For 18000 BTU, 230V, Cool Only / 18000 BTU, 230V, Heat Pump:



For 24000 BTU, 230V, Cool Only / 24000 BTU, 230V, Heat Pump:



6 Installation Details

6.1 Wrench torque sheet for installation

Outside diameter		Torque	Additional tightening torque
Φ6.35mm	1/4in	1500N.cm (11 Lbf.Ft.)	1600N.cm (12 Lbf.Ft.)
Φ9.52mm	3/8in	2500N.cm (18 Lbf.Ft.)	2600N.cm (19 Lbf.Ft.)
Φ12.7mm	1/2in	3500N.cm (26 Lbf.Ft.)	3600N.cm (27 Lbf.Ft.)
Φ15.9mm	5/8in	4500N.cm (33 Lbf.Ft.)	4700N.cm (35 Lbf.Ft.)
Φ19mm	3/4in	6500N.cm (48 Lbf.Ft.)	6700N.cm (50Lbf.Ft)

6.2 Connecting the cables

The power cord should be selected according to the following specifications sheet.

Appliance Amps	AWG Wire Size
10	18
13	16
18	14
25	12
30	10

The cable size and the current of the fuse or switch are determined by the maximum current indicated on the nameplate which located on the side panel of the unit. Please refer to the nameplate before selecting the cable, fuse and switch.

6.3 Pipe length and the elevation

Models	Pipe size	
	Gas	Liquid
WE009AMF15CLD + AN009AMF15RPD	3/8in (Φ9.52mm)	1/4in (Φ6.35mm)
WE009AMF15HLD + YN009AMF15RPD	3/8in (Φ9.52mm)	1/4in (Φ6.35mm)
WE009GMF15HLD + YN009GMF15RPD	3/8in (Φ9.52mm)	1/4in (Φ6.35mm)
WE012AMF15CLD + AN012AMF15RPD	1/2in (Φ12.7mm)	1/4in (Φ6.35mm)
WE012AMF15HLD + YN012AMF15RPD	1/2in (Φ12.7mm)	1/4in (Φ6.35mm)
WE012GMF15CLD + AN012GMF15RPD	3/8in (Φ9.52mm)	1/4in (Φ6.35mm)
WE012GMF15HLD + YN012GMF15RPD	3/8in (Φ9.52mm)	1/4in (Φ6.35mm)
WE018GMF15CLD + AN018GMF15RPD	1/2in (Φ12.7mm)	1/4in (Φ6.35mm)
WE018GMF15HLD + YN018GMF15RPD	1/2in (Φ12.7mm)	1/4in (Φ6.35mm)
WE024GMF15CLD + AN024GMF15RPD	5/8in (Φ15.9mm)	3/8in (Φ9.52mm)
WE024GMF15HLD + YN024GMF15RPD	5/8in (Φ15.9mm)	3/8in (Φ9.52mm)

Models	Standard length	Max. Elevation	Max. Length A	Additional refrigerant
WE009AMF15CLD + AN009AMF15RPD	7.5m (24.6ft)	10m (32.8ft)	25m (82.0ft)	15g/m (0.16oz/ft)
WE009AMF15HLD + YN009AMF15RPD	7.5m (24.6ft)	10m (32.8ft)	25m (82.0ft)	15g/m (0.16oz/ft)
WE009GMF15HLD + YN009GMF15RPD	7.5m (24.6ft)	10m (32.8ft)	25m (82.0ft)	15g/m (0.16oz/ft)
WE012AMF15CLD + AN012AMF15RPD	7.5m (24.6ft)	10m (32.8ft)	25m (82.0ft)	15g/m (0.16oz/ft)
WE012AMF15HLD + YN012AMF15RPD	7.5m (24.6ft)	10m (32.8ft)	25m (82.0ft)	15g/m (0.16oz/ft)
WE012GMF15CLD + AN012GMF15RPD	7.5m (24.6ft)	10m (32.8ft)	25m (82.0ft)	15g/m (0.16oz/ft)

WE012GMF15HLD + YN012GMF15RPD	7.5m (24.6ft)	10m (32.8ft)	25m (82.0ft)	15g/m (0.16oz/ft)
WE018GMF15CLD + AN018GMF15RPD	7.5m (24.6ft)	20m (65.6ft)	30m (98.4ft)	15g/m (0.16oz/ft)
WE018GMF15HLD + YN018GMF15RPD	7.5m (24.6ft)	20m (65.6ft)	30m (98.4ft)	15g/m (0.16oz/ft)
WE024GMF15CLD + AN024GMF15RPD	7.5m (24.6ft)	25m (82.0ft)	50m (164ft)	30g/m (0.32oz/ft)
WE024GMF15HLD + YN024GMF15RPD	7.5m (24.6ft)	25m (82.0ft)	50m (164ft)	30g/m (0.32oz/ft)

6.4 Installation for the first time

Air and moisture in the refrigerant system will cause undesirable effects as below:


- Pressure in the system rises.
- Operating current rises.
- Cooling or heating efficiency drops.
- Moisture in the refrigerant circuit may freeze and block capillary tubing.
- Water may lead to corrosion of parts in the refrigerant system (compressor damage).

Therefore, the indoor units and the pipes between indoor and outdoor units must be leak tested and evacuated to remove the air and moisture from the system.

Gas leak check (Soap water method):

Apply soap water or a liquid neutral detergent on the indoor unit connections or outdoor unit connections by a soft brush to check for leakage of the connecting points of the piping. If bubbles come out, the pipes have leakage.


1. Air evacuation using a vacuum pump



- 1) Completely tighten the flare nuts of the indoor and outdoor units, confirm that both the 2-way and 3-way valves are set to the closed position.
- 2) Connect the charging manifold's Low Side hose with the push pin to the 3-way valve's gas service port. (it is a 5/16" SAE Port).
- 3) Connect the charging manifold's Center hose the vacuum pump.
- 4) Fully open the Low Side Valve of the manifold.

- 5) Operate the vacuum pump to evacuate.
- 6) Make evacuation for 30 minutes and check whether the compound meter indicates **-0.1Mpa(14.5Psi)**. If the meter does not indicate **-0.1Mpa(14.5Psi)** after pumping 30 minutes, it should be pumped 20 minutes more. If the pressure can't achieve **-0.1Mpa(14.5Psi)** after pumping 50 minutes, please check if there are some leakage points. Fully close the Low side valve of the manifold and stop the vacuum pump. Confirm that the gauge needle does not rise (approximately 15 minutes after turning off the vacuum pump).
- 7) Turn the 3-way valve's stem about 45° counterclockwise to open a little for 6 or 7 seconds. Then tighten the valve stem again. Make sure the pressure display in the pressure indicator is a higher than the atmosphere pressure. Then remove the charge hose from the 3 way valve.
- 8) Fully open the 2 way valve and 3 way valve and securely tighten the caps of both valves. **CHECK FOR LEAKS AGAIN.**

2. Air purging by refrigerant



Procedure:

- 1). Confirm that both the 2-way and 3-way valves are set to the closed position.
- 2). Connect the charge manifold set and a charging cylinder to the service port of the 3-way valve (5/16" SAE Port).
- 3). Air purging.
Open the valves on the charging cylinder and the charge manifold set. Purge the air by loosening the flare nut on the 2-way valve approximately 45° for 3 seconds then closing it for 1 minute; repeat 3 times.

After purging the air, use a torque wrench to tighten the flare nut on the 2-way valve.

4). Check for gas leakage.

Check the flare connections for gas leakage.

5). Discharge the refrigerant.

Close the valve on the charging cylinder and discharge the refrigerant by loosening the flare nut on the 2-way valve approximately 45° until the gauge indicates **0.3Mpa(43.5Psi) to 0.5 Mpa(72.5Psi)**.

6). Disconnect the charge set and the charging cylinder, and open both the 2-way and 3-way valves to the fully open position.


Be sure to use proper sized hexagonal (Allen) wrench to operate the valve stems.

7). Mount the valve stem caps and the service port cap.

Be sure to use a torque wrench to tighten the service port cap to a torque 18N·m.

Be sure to check the gas leakage.

7.5 Adding the refrigerant after running the system for many years (Only recommended for systems that lack 10% of less of their total refrigerant volume. If more refrigerant needs to be added, than remove the remaining refrigerant and recharge entirely).



Procedure

1). Connect the charge hose to the 3-way valve's service port, while the 2-way valve and the 3-way valves are fully open.

Connect the charge hose to the valve at the bottom of the cylinder. If the refrigerant is R410A, make the cylinder upside down to ensure liquid charge.

2). Purge the air from the charge hose.

Open the valve at the bottom of the cylinder and press the check valve on the charge set to purge the air (be careful of the liquid refrigerant).

3) Put the charging cylinder onto the electronic scale and record the weight.

4) Operate the air conditioner at the cooling mode.

5) Open the valves (Low side) on the charging manifold set and charge the system with liquid refrigerant.

6).When the electronic scale displays the proper weight (refer to the gauge and the pressure of the low side), disconnect the charge hose from the 3-way valve's service port immediately and turn off the air conditioner before disconnecting the hose.

7). Mount the valve stem caps and the service port cap.


Use torque wrench to tighten the service port cap to a torque of 18N.m.

Be sure to check for gas leakage.

Be sure to check the gas leakage.

7.6 Re-installation while the indoor unit needs to be repaired

1. Collecting the refrigerant into the outdoor unit



Procedure

1). Confirm that both the 2-way and 3-way valves are set to the opened position. Remove the valve stem caps and confirm that the valve stems are in the opened position.

Be sure to use a proper size hexagonal (Allen) wrench to operate the valve stems.

2). Connect the Low side hose of the charging

manifold hose with the push pin to the 3-way valve's gas service port.

3). Air purge of the charge hose.

Open the Low side valve of the manifold slightly to purge air from the charge hose for 5 seconds and then close it quickly.

4). Set the 2-way valve to the close position.

5). Operate the air conditioner at the cooling cycle and stop it when the gauge indicates **0.1Mpa(14.5Psi)**.

6). Set the 3-way valve to the closed position immediately


Do this quickly so that the gauge ends up indicating **0.3Mpa(43.5Psi) to 0.5 Mpa(72.5Psi)**.

Disconnect the charge set, and tighten the 2-way and 3-way valve's stem nuts.

Use a torque wrench to tighten the 3-way valves service port cap to a torque of 18N.m.

Be sure to check for gas leakage.

2. Air purging by the refrigerant



Procedure:

- 1). Confirm that both the 2-way and 3-way valves are set to the closed position.
- 2). Connect the charge set and a charging cylinder to the service port of the 3-way valve. Leave the valve on the charging cylinder closed.
- 3). Air purging.

Open the valves on the charging cylinder and the charge set. Purge the air by loosening the flare nut on the 2-way valve approximately 45' for 3 seconds then closing it for 1 minute; repeat 3 times.

After purging the air, use a torque wrench to tighten the flare nut on the 2-way valve.

4). Check the gas leakage

Check the flare connections for gas leakage.

5). Discharge the refrigerant.

Close the valve on the charging cylinder and discharge the refrigerant by loosening the flare nut on the 2-way valve approximately 45' until the gauge indicates **0.3Mpa(43.5Psi) to 0.5 Mpa(72.5Psi)**.

6). Disconnect the charge set and the charging cylinder, and set the 2-way and 3-way valves to the fully open position

Be sure to use a proper size hexagonal (Allen) wrench to operate the valve stems.


7). Mount the valve stems nuts and the service port cap

Be sure to use a torque wrench to tighten the service port cap to a torque 18N.m.

Be sure to check the gas leakage.

7.7 Re-installation while the outdoor unit needs to be repaired


1. Evacuation for the whole system



Procedure:

- 1). Confirm that both the 2-way and 3-way valves are set to the opened position.
- 2). Connect the vacuum pump to 3-way valve's service port.
- 3). Evacuate for approximately one hour. Confirm that the pressure gauge indicates **-0.1Mpa(14.5Psi)**.
- 4). Close the valve (Low side) on the charge set, turn off the vacuum pump, and confirm that the gauge needle does not move up (approximately 15 minutes after turning off the vacuum pump).
- 5). Disconnect the charging hose from the vacuum pump.

2. Refrigerant charging



Procedure:

1). Connect the charge hose to the charging cylinder, open the 2-way valve and the 3-way valve

Connect the charge hose which you disconnected from the vacuum pump to the valve at the bottom of the cylinder. If the refrigerant is R410A, make the cylinder upside down to ensure liquid charge.

2). Purge the air from the charging hose
Open the valve at the bottom of the cylinder and press the check valve on the charge set to purge the air (be careful of the liquid refrigerant).

3) Put the charging cylinder onto the electronic scale and record the weight.

4). Open the valve (Low side) on the charge set and charge the system with liquid refrigerant. ASSURE TO CHARGE a little at a time (approximately 150g or 5 Ounces each time), while operating the air conditioner in the cooling cycle; wait approximately 1 minute in between each charging load and then repeat the procedure.

5).When the electronic scale displays the proper weight, disconnect the charge hose from the 3-way valve's service port immediately
If the system has been charged with liquid refrigerant while operating the air conditioner, turn off the air conditioner before disconnecting the hose.

6). Mount the valve stem caps and the service port. Use torque wrench to tighten the service port cap to a torque of 18N.m. Be sure to check for gas leakage.

7. Operation Characteristics

Mode \ Temperature	Cooling operation	Heating operation	Drying operation
Room temperature	≥17°C (62°F)	≤30°C (86°F)	> 10°C (50°F)
Outdoor temperature	0°C ~ 50°C (32°F ~ 122°F)	-15°C ~ 30°C (5°F ~ 86°F)	0°C ~ 50°C (32°F ~ 122°F)
	-15°C ~ 50°C (5°F ~ 122°F) (For the models with low ambient cooling option)		

Notes:

°C	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27
°F	50	50	52	54	56	58	60	62	64	66	68	70	72	74	76	78	80	82
°C	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43		
°F	84	86	86	90	92	94	96	98	98	99	100	102	104	106	108	109		
°C	44	45	46	47	48	49	50											
°F	111	113	115	117	118	120	122											

$$\Delta T(^{\circ}\text{F}) = \frac{9\Delta T(^{\circ}\text{C})}{5}$$

CAUTION:

1. If the air conditioner is used beyond the above conditions, certain safety protection features may come into operation and cause the unit to operate abnormally.
2. The room relative humidity should be less than 80%. If the air conditioner operates beyond this figure, the surface of the air conditioner may attract condensation. Please set the vertical air flow louver to its maximum angle (vertically to the floor), and set HIGH fan mode.
3. The optimum performance will be achieved during this operating temperature zone.


8. Electronic Function


8.1 Abbreviation

- T1: Indoor room temperature
- T2: Coil temperature of evaporator
- T3: Coil temperature of condenser
- T4: Outdoor ambient temperature
- T5: Compressor discharge temperature

8.2 Display function

8.2.1 Icon explanation on indoor display board.



Defrost Indicator	This indicator illuminates when the air conditioner starts defrosting automatically or while the warm air control feature (warm-start) is activate in heating mode
Run indicator	Flash every 2 seconds when the unit is standby. Illuminate when the unit is turned on.
Timer indicator	This indicator illuminates when TIMER is set ON/OFF.
	Temperature indicator Displays the temperature settings when the air conditioner is operational. Also displays the malfunction code.

8.3 Main Protection

8.3.1 Three minutes delay at restart for compressor

1 minute delay for the 1st time start-up and 3 minute delay for subsequent starts.

8.3.2 Temperature protection of compressor top surface.

The unit will stop working when the compressor top temp. protector activates, and will restart after the compressor top temp. protector resets.

8.3.3 Temperature protection of compressor discharge pipe

When the compressor discharge temp. is getting higher, the running frequency will be limited as per the below rules:

---Compressor discharge temp. $T_5 > 115^\circ\text{C}$ for 5s, compressor stops.

--- $108 < T_5 < 115^\circ\text{C}$, decrease the frequency to one lower level every 3 minutes.

--- $90 < T_5 < 105^\circ\text{C}$, keep running at the current frequency.

---- $T_5 < 90^\circ\text{C}$, no limit for frequency.

8.3.4 Fan speed is out of control

When Indoor Fan Speed is measured too low (<300 RPM) for certain time, the unit will stop and the LED will display the failure.

8.3.5 Inverter module protection

The Inverter module has a protection function based on current, voltage and temperature. If these protections activate, the corresponding code will display on the indoor unit and the unit will stop working.

8.3.6 Indoor fan delayed start function

When the unit starts up, the louver will be activated immediately and the indoor fan will start 10s later.

If the unit runs in heating mode, the indoor fan will be also controlled by anti-cold draft (Warm Start) function. Indoor fan will start operating only after the indoor coil's surface temperature becomes hot enough. During this delay period, the defrost light will be illuminated

8.3.7 Compressor preheating functions

Preheating permitting condition:

If T_4 (outdoor ambient temperature) $< 3^\circ\text{C}$ and the machine is connected to the power supply

recently or if $T_4 < 3^\circ\text{C}$ and compressor has stopped for over 3 hours, the compressor heating circuit will activate.

Preheating mode:

A weak current flow through the coil of compressor through the wiring terminal of the compressor, then the compressor is kept warm without operating.

Preheating release condition:

If $T_4 > 5^\circ\text{C}$ or the compressor starts running, the preheating function will stop.

8.3.8 Zero crossing detection error protection

If IC detects that time interval is not correct continuously for 240s, the unit will stop and the LED will display the failure. The correct zero crossing signal time interval should be between 6-13ms.

8.3.9 Condenser temperature protection

--- $55^\circ\text{C} < T_3 < 60^\circ\text{C}$, the compressor frequency will decrease to the lower level until to F1 and then runs at F1. If $T_3 < 54^\circ\text{C}$, the compressor will keep running at the current frequency.

--- $T_3 < 52^\circ\text{C}$, the compressor will not limit the frequency and resume to the former frequency.

--- $T_3 > 60^\circ\text{C}$ for 5 seconds, the compressor will stop until $T_3 < 52^\circ\text{C}$.

8.3.10 Evaporator temperature protection

--- $T_2 < 0^\circ\text{C}$, the compressor will stop and restart when $T_2 \geq 5^\circ\text{C}$.

--- $0^\circ\text{C} \leq T_2 < 4^\circ\text{C}$, the compressor frequency will be limited and decreased to the lower level


--- $4^\circ\text{C} \leq T_2 \leq 7^\circ\text{C}$, the compressor will keep the current frequency.

--- $T_2 > 7^\circ\text{C}$, the compressor frequency will not be limited.

8.4 Operation Modes and Functions

8.4.1 Fan only mode


- (1) Outdoor fan and compressor stop.
- (2) Temperature setting function is disabled, and no set temperature is displayed.
- (3) Indoor fan can be set to high/med/low/auto.
- (4) The louver operates same as in cooling mode.
- (5) Auto fan:



8.4.2 Cooling Mode

8.4.2.1 Compressor running rules


The maximum operation frequency of compressor after starting is based on to the following rule.



Fmax: The maximum operation frequency of compressor.

F1~F8: The detailed value of the compressor operation frequency.

If users switch on the unit by remote controller, the compressor will run at the Fmax frequency for 7 minutes according to the outdoor ambient temp. During the 7 minutes, the frequency limitation is active. 7 minutes later, the compressor running frequency will be controlled as below:



While the zones of A,B,C... are corresponding to different compressor running frequencies.

Note:

When T1-Ts stays in the same temp. zone for 3 minutes, the compressor will run as the below rules:



A~E: Increase the frequency to the higher level until reaching F8.

F: Keep the current frequency.

G: Decrease the frequency to the lower level until reaching F1.

H: Run at F1 for 1h. (if $T1-Ts < -2^{\circ}\text{C}$, the compressor will stop)


Meanwhile, the compressor running frequency is limited by the current.



I3COOL, I2COOL, I1COOL mean different running current value.
 Off: Compressor stops.
 Decrease: Decrease the running frequency to the lower level.
 Hold: Keep the current frequency.
 Resume: No limitation for frequency.

Note:
 When AC is in "hold" zone for 3 minutes, the compressor frequency will rise to the higher level. (frequency will increase twice at most)

9.4.2.2 Outdoor fan running rules




9.4.2.3 Indoor fan running rules

In cooling mode, indoor fan runs all the time and the speed can be selected as high, medium, low and auto.
 Auto fan in cooling mode acts as follow:

8.4.3 Heating Mode

8.4.3.1 Compressor running rules

The maximum operation frequency of the compressor after starting is based on the following rule.




Fmax: The maximum operation frequency of compressor.

F1~F8: The detailed value of the compressor operation frequency.

If users switch on the unit by remote controller, the compressor will run at the Fmax frequency for 7 minutes according to outdoor ambient

temp. During the 7 minutes, the frequency limitation is active.

7 minutes later, the compressor running frequency will be controlled as below:



While the zones of A,B,C... are corresponding to different compressor running frequency.

$\Delta T = 0^\circ\text{C}$ as default.

Note:

When $T_1 - T_s$ keeps in the same temp. zone for 3 minutes, the compressor will run as per the below rules:


A~E: Increase the frequency to the higher level until reaching F10.

F: Keep the current frequency.

G: Decrease the frequency to the lower level until reaching F1.

H: Run at F1 for 1h.(if $T_1 - T_s - \Delta T > 6^\circ\text{C}$, the compressor will stop)

Meanwhile, the compressor running frequency is limited by the current.



I3HEAT, I2HEAT, I1HEAT mean different running current value.

Off: Compressor stops.

Decrease: Decrease the running frequency to the lower level.


Hold: Keep the current frequency.

Resume: No limitation for frequency.


Note:

When AC is in "hold" zone for 3 minutes, the compressor frequency will rise to the higher level. (The frequency will increase twice at most)

8.4.3.2 Outdoor fan running rules




8.4.3.3 Indoor fan running rules



If the compressor stops due to the room temperature rise, the indoor fan will be forced to run 127 seconds with breeze speed. During this period, the anti-cold (warm Start) is disabled.

If the machine runs in rating capacity test mode, the indoor fan will run with rated speed and the anti-cold (warm Start) function is disabled.

Auto fan action in heating mode:



8.4.3.4 Defrosting mode

Condition of defrosting:

--- $T4 > 0^{\circ}\text{C}$,

When the units are running, if the following two items are satisfied, the units start defrosting:

The units run with $T3 < 3^{\circ}\text{C}$ for 40 minutes and $T3$ stays lower than $\text{TCDI}^{\circ}\text{C}$ for more than 3 minutes.

The units run with $T3 < 3^{\circ}\text{C}$ for 80 minutes and $T3$ stays lower than $\text{TCDI} + 2^{\circ}\text{C}$ for more than 3 minutes.

--- $T4 < 0^{\circ}\text{C}$,

If the 1st condition and 2nd condition items are satisfied, then the program judges if $T2$ has decreased more than 5°C . When $T2$ has decreased more than 5°C , system will enter the defrost mode.

---No matter what value $T4$ is, if the machine runs with $T3 < 3^{\circ}\text{C}$ for more than 120 minutes and $T3$ keeps lower than $\text{TCDI} + 4^{\circ}\text{C}$ for more than 3 minutes, the machine will enter the defrost mode no matter if $T2$ drops by more than 5°C or not.

Condition of ending defrosting:

If any one of the following items is satisfied, the defrosting will finish and the machine will turn to normal heating mode.


--- $T3$ rises to be higher than $\text{TCDE} 1^{\circ}\text{C}$.

--- $T3$ keeps to be higher than $\text{TCDE} 2^{\circ}\text{C}$ for 80 seconds.

---The machine has run for 10 minutes in defrosting mode.


Defrosting action:

For 9k,12k models:



xx=60s.

For 18k, 24k models:



XX=60 for 18k model, XX=90 for 24k model.

8.4.3.5 Evaporator coil temperature protection

--- $T_2 > TEH2^\circ C$, the compressor running frequency decreases to the lower level and runs for 20s.

When the frequency decreases to F2 and the T2 is still over $TEH2^\circ C$ for 3 minutes, the compressor will stop.

--- $T_2 < 48^\circ C$ or T2 stays in $48^\circ C \sim TEH2^\circ C$ for 6 minutes, the frequency will not be limited by T2.

--- $T_2 > 60^\circ C$, the compressor will stop and restart when $T_2 < 48^\circ C$.

8.4.4 Auto-mode

This mode can be chosen with remote controller and the setting temperature can be changed between $17 \sim 30^\circ C$.

In auto mode, the machine will choose cooling, heating or fan-only mode according to ΔT ($\Delta T = T_1 - T_s$).

$\Delta T = T_1 - T_s$	Running mode
$\Delta T > 1^\circ C$	Cooling
$-1 < \Delta T \leq 1^\circ C$	Fan-only
$\Delta T \leq -1^\circ C$	Heating

Indoor fan will run at auto fan of the relevant mode.


The louver operates same as in relevant mode. If the machine switches mode between heating and cooling, the compressor will stop for 15 minutes and then choose mode according to $T_1 - T_s$.

If the setting temperature is modified, the machine will re-determine the running function again.

8.4.5 Drying mode

8.4.5.1 Indoor fan speed is fixed at breeze speed and can't be changed. The louver angle is the same as in cooling mode.

8.4.5.2 Compressor running rules



8.4.5.3 Low indoor room temperature protection

In drying mode, if room temperature is lower than $10^\circ C$, the compressor will stop and not resume until room temperature exceeds $12^\circ C$.

8.4.5.4 Evaporator anti-freezing protection, condenser high temperature protection and outdoor unit frequency limit are active and the same as that in cooling mode.

8.4.5.5 The outdoor fan operates the same as in cooling mode.

8.4.6 Forced operation function

8.4.6.1 Enter forced operation function:

When the machine is off, pressing the EMERGENCY touch button will switch the unit into forced auto mode. While in Auto Mode, pressing and holding the button once again within 5 seconds, will switch the unit into forced cooling mode. In forced auto, forced cooling or any other operation mode, pressing touch button will turn off the system.

8.4.6.2 In forced operation mode, all general protections and remote control is available.

8.4.6.3 Operation rules:

Forced cooling mode:

The compressor runs at F2 frequency and indoor fan runs as breeze speed. After running for 30 minutes. the machine will turn to auto mode with 24°C setting temperature.

Forced auto mode:

The action of forced auto mode is the same as normal auto mode with 24°C setting temperature.

8.4.7 Timer function

8.4.7.1 Timing adjustable range is 24 hours.

8.4.7.2 Timer on. The system will turn on automatically when reaching the set time.

8.4.7.3 Timer off. The system will turn off automatically when reaching the set time.

8.4.7.4 Timer on/off. The system will turn on automatically when reaching the set "on" time, and then turn off automatically when reaching the set "off" time.

8.4.7.5 Timer off/on. The system will turn off automatically when reaching the set "off" time, and then turn on automatically when reaching the set "on" time.

8.4.7.6 The timer function will not change the unit's current operation mode. If the unit is off now, it will not start after setting the "timer off" function. And when reaching the setting time, the timer LED will be off and the running mode will not be changed.

8.4.7.7 The setting time is relative time.

8.4.8 Sleep function mode

8.4.8.1 Operation time in sleep mode is 7 hours. After 7 hours the system quits this mode and turns off.

8.4.8.2. Operation process in sleep mode is as follows:

When cooling, the setting temperature rises 1°C (if room is lower than 30°C) every one hour, 2 hours later the setting temperature stops rising and indoor fan is fixed as low speed.

When heating, the setting temperature decreases 1°C (if room is higher than 17°C) every one hour, 2 hours later the setting temperature stops rising and indoor fan is fixed as low speed. (Warm-Start function has the priority)

8.4.8.3 Timer setting is available

8.4.8.4 When user uses timer off function in sleep mode (or sleep function in timer off mode), if the timing is less than 7 hours, sleep function will be cancelled when reaching the setting time. If the timing is more than 7 hours, the machine will not stop until reaching the set time in sleep mode.

8.4.9 Auto-Restart function

The indoor unit is equipped with auto-restart function, which is carried out through an auto-restart memory module. In case of a sudden power failure, the module memorizes the setting conditions before the power failure. The unit will resume the previous operation setting (not including swing function) automatically after 3 minutes when power returns.

If the auto restart condition occurs in forced cooling mode, the unit will run in cooling mode for 30 minutes and turn to auto mode at 24°C set temp.

If system is off before power goes out it will stay off. When the unit is started up by the user, the compressor will have 1 minute delay. For other conditions, the compressor will have 3 minutes delay when restarts.


8.4.10 8°C Heating (Vacation Mode - Optional)

In heating operation, the preset temperature of the air conditioner can be as lower as 8°C, which keeps the room temperature steady at 8°C and prevents household items from freezing when the house is unoccupied for a long time in severe cold weather (Vacation Mode)


9. Troubleshooting

Safety

Electricity power is still kept in capacitors even the power supply is shut off. Do not forget to discharge the electricity power in capacitor.



For other models, please connect discharge resistance (approx. 100Ω 40W) or soldering iron (plug) between +, - terminals of the electrolytic capacitor on the contrary side of the outdoor PCB.




Note: The picture above is only for reference. The plug of your side may be different.

9.1 Indoor Unit Error Display

Operation lamp	Timer lamp	Display	LED STATUS
☆ 1 time	X	E0	Indoor unit EEPROM parameter error
☆ 2 times	X	E1	Indoor / outdoor units communication error
☆ 3 times	X	E2	Zero-crossing signal detection error
☆ 4 times	X	E3	Indoor fan speed has been out of control
☆ 5 times	X	E4	Indoor room temperature sensor T1 open circuit or short circuit
☆ 6 times	X	E5	Evaporator coil temperature sensor T2 open circuit or short circuit
☆ 7 times	X	EC	Refrigerant leakage detection
☆ 2 times	O	F1	Outdoor temperature sensor T4 open circuit or short circuit
☆ 3 times	O	F2	Condenser coil temperature sensor T3 open circuit or short circuit
☆ 4 times	O	F3	Compressor discharge temperature sensor T5 open circuit or short circuit
☆ 5 times	O	F4	Outdoor unit EEPROM parameter error
☆ 1 times	☆	P0	IPM malfunction or IGBT over-strong current protection
☆ 2 times	☆	P1	Over voltage or Under voltage protection
☆ 3 times	☆	P2	High temperature protection of compressor top
☆ 5 times	☆	P4	Inverter compressor drive error

9.2 Outdoor unit error display

- For 9000 BTU, 230V, Heat Pump / 12000 BTU, 230V, Cool Only / 12000 BTU, 230V, Heat Pump:




LED1

There's a LED light on the outdoor PCB which is blue color.


After power on, it will be slow flash (once 5 secs) when the unit is in standby and quick flash (2.5 per sec) if the unit has some problems.

- For 9000 BTU, 115V, Cool Only / 9000 BTU, 115V, Heat Pump / 12000 BTU, 115V, Cool Only / 12000 BTU, 115V, Heat Pump:



There's a LED light on the outdoor PCB which is blue color.
 After power on, it will be slow flash (once 5 secs) when the unit is in standby and quick flash (2.5 per sec) if the unit has some problems.

➤ For 18000 BTU, 230V, Cool Only / 18000 BTU, 230V, Heat Pump:



LED1 (red)	LED2 (yellow)	LED3 (green) & LED4 (red)
------------	---------------	---------------------------

	standby	operating
LED2	slow flashing	on
LED1	on	on

The picture of PCB above is only for reference.

LED 1 is a red light and for the PCB POWER display.


LED 2 is a yellow light. After power on, it will be slow flash (once every 5 secs) when the unit is in standby and quick flash (2.5 per sec) if the unit has some problems, it will be always on when the unit is in operation.

LED 4 (green) and LED3 (red) are two lights controlled by the compressor driver chip. Below are the meanings for those lights.

No.	Problems	LED3 (Green)	LED4 (Red)	IU display
1	standby for normal	O	X	
2	Operation normal	X	O	
3	IPM malfunction or IGBT over-strong current protection	☆	X	P0
4	Over voltage or too low voltage protection	O	O	P1
5	Over voltage or too low voltage protection	O	☆	P1
6	Inverter compressor drive error	X	☆	P4
7	Inverter compressor drive error	☆	O	P4
8	Inverter compressor drive error	☆	☆	P4

O (light) X (off) ☆ (2.5Hz flash)

For 24000 BTU, 230V, Cool Only / 24000 BTU, 230V, Heat Pump:



LED1

There's a LED light on the outdoor PCB which is blue color.

After power on, it will be slow flash (once 5 secs) when the unit is in standby and quick flash (2.5 per sec) if the unit has some problems.


9.3 Diagnosis and Solution

9.3.1 EEPROM parameter error diagnosis and solution(E0/F4)


Error Code	E0/F4
Malfunction decision conditions	Indoor or outdoor PCB main chip does not receive feedback from EEPROM chip.
Supposed causes	<ul style="list-style-type: none"> ● Installation mistake ● PCB faulty

Trouble shooting:

Shut off the power supply and turn it on 5 seconds later. Is it still displaying the error code ?



EEPROM: a read-only memory whose contents can be erased and reprogrammed using a pulsed voltage. For the location of EEPROM chip, please refer to the below photos.



Indoor PCB



Outdoor PCB


Note: The two photos above are only for reference, it's may be not same totally with the ones on your system.

9.3.2 Indoor / outdoor unit's communication diagnosis and solution(E1)

Error Code	E1
Malfunction decision conditions	Indoor unit does not receive the feedback from outdoor unit during 110 seconds and this condition happens four times continuously.
Supposed causes	<ul style="list-style-type: none"> ● Wiring mistake ● Indoor or outdoor PCB faulty

Trouble shooting:

Power off, then turn on the unit 5 seconds later(reconnect the power wire).Is the error still displaying after several minutes?



NOTE: Measure the voltage between N and S Terminals (instead of L2 and S as indicated above) for the 115 VAC Models. L2 terminal is available only on the 230 VAC Systems.




Remark:

Use a multimeter to test the **DC** voltage between L2 (or N on 115 V Models) port and S port of outdoor unit. The red pin of multimeter connects with L2 (or N on 115 V Models) port while the black pin is for S port.

When AC is normally running, the voltage will move alternately between -50V to 50V.

If the outdoor unit has malfunction, the voltage will move alternately with positive value.

While if the indoor unit has malfunction, the voltage will be a certain value.




Remark:

Use a multimeter to test the resistance of the reactor (one that is not connected with a capacitor). The normal value should be around zero ohm. Otherwise, the reactor must have malfunction and need to be replaced.

9.4.3 Zero crossing detection error diagnosis and solution(E2)

Error Code	E2
Malfunction decision conditions	When PCB does not receive zero crossing signal feedback for 4 minutes or the zero crossing signal time interval is abnormal.
Supposed causes	<ul style="list-style-type: none">● Connection mistake● PCB faulty


Trouble shooting:



9.4.4 Fan speed has been out of control diagnosis and solution(E3)

Error Code	E3
Malfunction decision conditions	When indoor fan speed stays too low (<300RPM) for certain time, the unit will stop and the LED will display the failure.
Supposed causes	<ul style="list-style-type: none"> ● Wiring mistake ● Fan assembly fault (check for rubbing/misalignment) ● Fan motor faulty ● PCB faulty


Trouble shooting:



Index 1:

1. Indoor AC fan motor

Measure the resistance value of each winding by using the tester.




For the definite value of the resistance, refer to page 61 and page 64.

Index2:

1: Indoor AC fan motor



Power on and set the unit running in fan mode at high fan speed. After running for 15 seconds, measure the voltage of pin1 and pin2. If the value of the voltage is less than 100V (208~240V power supply) or 50V (115V power supply), the PCB must have problems and need to be replaced.



9.4.5 Open circuit or short circuit of temperature sensor diagnosis and solution(E5)

Error Code	E5
Malfunction decision conditions	If the sampling voltage is lower than 0.06V or higher than 4.94V, the LED will display the failure.
Supposed causes	<ul style="list-style-type: none"> ● Wiring mistake ● Sensor faulty


Trouble shooting:



9.4.6 Refrigerant Leakage Detection diagnosis and solution(EC)

Error Code	EC
Malfunction decision conditions	<p>Define the evaporator coil temp.T2 of the compressor just starts running as Tcool.</p> <p>In the beginning 5 minutes after the compressor starts up, if $T2 < T_{cool} - 2^{\circ}\text{C}$ does not keep continuous 4 seconds and this situation happens 3 times, the display area will show “EC” and AC will turn off.</p>
Supposed causes	<ul style="list-style-type: none"> ● T2 sensor faulty ● Indoor PCB faulty ● System problems, such as leakage or blocking.


Trouble shooting:



9.4.7 IPM malfunction or IGBT over-strong current protection diagnosis and solution(P0)


Error Code	P0
Malfunction decision conditions	When the voltage signal that IPM send to compressor drive chip is abnormal, the display LED will show “P0” and AC will turn off.
Supposed causes	Wiring mistake; IPM malfunction; Outdoor fan ass’y faulty Compressor malfunction; Outdoor PCB faulty

Trouble shooting:




Remark:


- 1) 9000 BTU, 230 VAC both Cool Only and Heat Pump models: Measure the **black** pin and **red** pin of the motor connector, the resistance should be around **385Ω** at 20°C(68°F)
- 2) 9000 BTU and 12000 BTU, 115 VAC both Cool Only and Heat Pump models: Measure the **black** pin and **red** pin of the motor connector, the resistance should be around **50Ω** at 20°C(68°F)
- 3) 12000 BTU, 230 VAC both Cool Only and Heat Pump models: Measure the **black** pin and **red** pin of the motor connector, the resistance should be around **293Ω** at 20°C(68°F)
- 4) 18000 BTU, 230 VAC both Cool Only and Heat Pump models: Measure the **black** pin and **red** pin of the motor connector, the resistance should be around **84.5Ω** at 20°C(68°F)
- 5) 24000 BTU, 230 VAC both Cool Only and Heat Pump models: Measure the **black** pin and **red** pin of the motor connector, the resistance should be around **88.5Ω** at 20°C(68°F)




P-U



P-V



P-W




P-N

9.4.8 Over voltage or too low voltage protection diagnosis and solution(P1)

Error Code	P1
Malfunction decision conditions	An abnormal voltage rise or drop is detected by checking the specified voltage detection circuit.
Supposed causes	<ul style="list-style-type: none"> ● Power supply problems. ● System leakage or block ● PCB faulty

Trouble shooting:




Remark:

Measure the DC voltage between P and N (P and L2 for 230V Systems) port. The normal value should be around 310V.

9.4.9 High temperature protection of compressor top diagnosis and solution(P2)

Error Code	P2
Malfunction decision conditions	If the sampling voltage is not 5V, the LED will display the failure.
Supposed causes	<ul style="list-style-type: none"> ● Power supply problems. ● System leakage or block ● PCB faulty


Trouble shooting:



9.4.10 Inverter compressor drive error diagnosis and solution(P4)

Error Code	P4
Malfunction decision conditions	An abnormal inverter compressor drive is detected by a special detection circuit, including communication signal detection, voltage detection, compressor rotation speed signal detection and so on.
Supposed causes	Wiring mistake; IPM malfunction; Outdoor fan ass'y faulty Compressor malfunction; Outdoor PCB faulty

Trouble shooting:




Remark:

- 1) 9000 BTU, Heat Pump, 230V model: Measure the **black** pin and **red** pin of the motor connector, the resistance should be around **385Ω** at 20°C(68°F)
- 2) 9000 BTU and 12000 BTU 115 VAC Models, Both Cool Only and Heat Pump: Measure the **black** pin and **red** pin of the motor connector, the resistance should be around **50Ω** at 20°C(68°F)
- 3) 12000 BTU 230 VAC Models, Both Cool Only and Heat Pump: Measure the **black** pin and **red** pin of the motor connector, the resistance should be around **293Ω** at 20°C(68°F)
- 4) 18000 BTU 230 VAC Models, Both Cool Only and Heat Pump: Measure the **black** pin and **red** pin of the motor connector, the resistance should be around **84.5Ω** at 20°C(68°F)
- 5) 24000 BTU 230 VAC Models, Both Cool Only and Heat Pump: Measure the **black** pin and **red** pin of the motor connector, the resistance should be around **88.5Ω** at 20°C(68°F)

Main parts check

1. Temperature sensor checking

Disconnect the temperature sensor from PCB, measure the resistance value with a tester.



Tester

Temperature Sensors.

Room temp.(T1) sensor,

Indoor coil temp.(T2) sensor,

Outdoor coil temp.(T3) sensor,

Outdoor ambient temp.(T4) sensor,

Compressor discharge temp.(T5) sensor.

Measure the resistance value of each winding by using the multi-meter.

Appendix 1 Temperature Sensor Resistance Value Table for T1,T2,T3,T4 (°C--K)

°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm
-20	-4	115.266	20	68	12.6431	60	140	2.35774	100	212	0.62973
-19	-2	108.146	21	70	12.0561	61	142	2.27249	101	214	0.61148
-18	0	101.517	22	72	11.5	62	144	2.19073	102	216	0.59386
-17	1	96.3423	23	73	10.9731	63	145	2.11241	103	217	0.57683
-16	3	89.5865	24	75	10.4736	64	147	2.03732	104	219	0.56038
-15	5	84.219	25	77	10	65	149	1.96532	105	221	0.54448
-14	7	79.311	26	79	9.55074	66	151	1.89627	106	223	0.52912
-13	9	74.536	27	81	9.12445	67	153	1.83003	107	225	0.51426
-12	10	70.1698	28	82	8.71983	68	154	1.76647	108	226	0.49989
-11	12	66.0898	29	84	8.33566	69	156	1.70547	109	228	0.486
-10	14	62.2756	30	86	7.97078	70	158	1.64691	110	230	0.47256
-9	16	58.7079	31	88	7.62411	71	160	1.59068	111	232	0.45957
-8	18	56.3694	32	90	7.29464	72	162	1.53668	112	234	0.44699
-7	19	52.2438	33	91	6.98142	73	163	1.48481	113	235	0.43482
-6	21	49.3161	34	93	6.68355	74	165	1.43498	114	237	0.42304
-5	23	46.5725	35	95	6.40021	75	167	1.38703	115	239	0.41164
-4	25	44	36	97	6.13059	76	169	1.34105	116	241	0.4006
-3	27	41.5878	37	99	5.87359	77	171	1.29078	117	243	0.38991
-2	28	39.8239	38	100	5.62961	78	172	1.25423	118	244	0.37956
-1	30	37.1988	39	102	5.39689	79	174	1.2133	119	246	0.36954
0	32	35.2024	40	104	5.17519	80	176	1.17393	120	248	0.35982
1	34	33.3269	41	106	4.96392	81	178	1.13604	121	250	0.35042
2	36	31.5635	42	108	4.76253	82	180	1.09958	122	252	0.3413
3	37	29.9058	43	109	4.5705	83	181	1.06448	123	253	0.33246
4	39	28.3459	44	111	4.38736	84	183	1.03069	124	255	0.3239
5	41	26.8778	45	113	4.21263	85	185	0.99815	125	257	0.31559
6	43	25.4954	46	115	4.04589	86	187	0.96681	126	259	0.30754
7	45	24.1932	47	117	3.88673	87	189	0.93662	127	261	0.29974
8	46	22.5662	48	118	3.73476	88	190	0.90753	128	262	0.29216
9	48	21.8094	49	120	3.58962	89	192	0.8795	129	264	0.28482
10	50	20.7184	50	122	3.45097	90	194	0.85248	130	266	0.2777
11	52	19.6891	51	124	3.31847	91	196	0.82643	131	268	0.27078
12	54	18.7177	52	126	3.19183	92	198	0.80132	132	270	0.26408
13	55	17.8005	53	127	3.07075	93	199	0.77709	133	271	0.25757
14	57	16.9341	54	129	2.95896	94	201	0.75373	134	273	0.25125
15	59	16.1156	55	131	2.84421	95	203	0.73119	135	275	0.24512
16	61	15.3418	56	133	2.73823	96	205	0.70944	136	277	0.23916
17	63	14.6181	57	135	2.63682	97	207	0.68844	137	279	0.23338
18	64	13.918	58	136	2.53973	98	208	0.66818	138	280	0.22776
19	66	13.2631	59	138	2.44677	99	210	0.64862	139	282	0.22231

Appendix 2 Temperature Sensor Resistance Value Table for T5 (°C--K)

°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm
-20	-4	542.7	20	68	68.66	60	140	13.59	100	212	3.702
-19	-2	511.9	21	70	65.62	61	142	13.11	101	214	3.595
-18	0	483	22	72	62.73	62	144	12.65	102	216	3.492
-17	1	455.9	23	73	59.98	63	145	12.21	103	217	3.392
-16	3	430.5	24	75	57.37	64	147	11.79	104	219	3.296
-15	5	406.7	25	77	54.89	65	149	11.38	105	221	3.203
-14	7	384.3	26	79	52.53	66	151	10.99	106	223	3.113
-13	9	363.3	27	81	50.28	67	153	10.61	107	225	3.025
-12	10	343.6	28	82	48.14	68	154	10.25	108	226	2.941
-11	12	325.1	29	84	46.11	69	156	9.902	109	228	2.86
-10	14	307.7	30	86	44.17	70	158	9.569	110	230	2.781
-9	16	291.3	31	88	42.33	71	160	9.248	111	232	2.704
-8	18	275.9	32	90	40.57	72	162	8.94	112	234	2.63
-7	19	261.4	33	91	38.89	73	163	8.643	113	235	2.559
-6	21	247.8	34	93	37.3	74	165	8.358	114	237	2.489
-5	23	234.9	35	95	35.78	75	167	8.084	115	239	2.422
-4	25	222.8	36	97	34.32	76	169	7.82	116	241	2.357
-3	27	211.4	37	99	32.94	77	171	7.566	117	243	2.294
-2	28	200.7	38	100	31.62	78	172	7.321	118	244	2.233
-1	30	190.5	39	102	30.36	79	174	7.086	119	246	2.174
0	32	180.9	40	104	29.15	80	176	6.859	120	248	2.117
1	34	171.9	41	106	28	81	178	6.641	121	250	2.061
2	36	163.3	42	108	26.9	82	180	6.43	122	252	2.007
3	37	155.2	43	109	25.86	83	181	6.228	123	253	1.955
4	39	147.6	44	111	24.85	84	183	6.033	124	255	1.905
5	41	140.4	45	113	23.89	85	185	5.844	125	257	1.856
6	43	133.5	46	115	22.89	86	187	5.663	126	259	1.808
7	45	127.1	47	117	22.1	87	189	5.488	127	261	1.762
8	46	121	48	118	21.26	88	190	5.32	128	262	1.717
9	48	115.2	49	120	20.46	89	192	5.157	129	264	1.674
10	50	109.8	50	122	19.69	90	194	5	130	266	1.632
11	52	104.6	51	124	18.96	91	196	4.849			
12	54	99.69	52	126	18.26	92	198	4.703			
13	55	95.05	53	127	17.58	93	199	4.562			
14	57	90.66	54	129	16.94	94	201	4.426			
15	59	86.49	55	131	16.32	95	203	4.294			
16	61	82.54	56	133	15.73	96	205	4.167			
17	63	78.79	57	135	15.16	97	207	4.045			
18	64	75.24	58	136	14.62	98	208	3.927			
19	66	71.86	59	138	14.09	99	210	3.812			


Appendix 3:

°C	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27
°F	50	50	52	54	56	58	60	62	64	66	68	70	72	74	76	78	80	82
°C	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43		
°F	84	86	86	90	92	94	96	98	98	99	100	102	104	106	108	109		
°C	44	45	46	47	48	49	50											
°F	111	113	115	117	118	120	122											

$$\Delta T(^{\circ}\text{F}) = \frac{9\Delta T(^{\circ}\text{C})}{5}$$

2.Compressor checking

Measure the resistance value of each winding by using the tester.



Position	Resistance Value			
	DA108X1C-23EZ	DA108X1C-20FZ3	DA130M1C-31FZ	DA150S1C-20FZ
Blue - Red	1.1Ω	0.71Ω	1.77Ω	0.95Ω
Blue - Black	(20°C/68°F)	(20°C/68°F)	(20°C/68°F)	(20°C/68°F)
Red - Blue				




3. IPM continuity check

Turn off the power, let the large capacity electrolytic capacitors discharge completely, and dismount the IPM. Use a digital tester to measure the resistance between P and UVWN; UVW and N.

Digital tester		Normal resistance value	Digital tester		Normal resistance value
(+)Red	(-)Black		(+)Red	(-)Black	
P	N	∞ (Several MΩ)	U	N	∞ (Several MΩ)
	U		V		
	V		W		
	W		(+)Red		

4: Indoor AC Fan Motor

Measure the resistance value of each winding by using the tester.



Position	Resistance Value					
	RPG13B	RPG15A	RPG20B	RPG28H	RPG45B	
Black - Red	530Ω±8% (20°C/68°F) (Brand: Weiling)	75Ω±8% (20°C/68°F) (Brand: Weiling)	381Ω±8% (20°C/68°F) (Brand: Weiling)	183.6Ω±8% (20°C/68°F) (Brand: Weiling)	112Ω±8% (20°C/68°F) (Brand: Weiling)	118.5Ω±8% (20°C/68°F) (Brand: Dayang)
White - Black	315Ω±8% (20°C/68°F) (Brand: Weiling)	150Ω±8% (20°C/68°F) (Brand: Weiling)	267Ω±8% (20°C/68°F) (Brand: Weiling)	206Ω±8% (20°C/68°F) (Brand: Weiling)	82Ω±8% (20°C/68°F) (Brand: Weiling)	78.5Ω±8% (20°C/68°F) (Brand: Dayang)


5: Pressure On Service Port

Cooling chart:

F(°C)	ODT		75	85	95	105	115
	IDT		(23.89)	(29.44)	(35)	(40.56)	(46.11)
BAR	70/59		8.2	7.8	8.1	8.6	10.1
BAR	75/63		8.6	8.3	8.7	9.1	10.7
BAR	80/67		9.3	8.9	9.1	9.6	11.2

F(°C)	ODT		75	85	95	105	115
	IDT		(23.89)	(29.44)	(35)	(40.56)	(46.11)
PSI	70/59		119	113	117	125	147
PSI	75/63		124	120	126	132	155
PSI	80/67		135	129	132	140	162

F(°C)	ODT		75	85	95	105	115
	IDT		(23.89)	(29.44)	(35)	(40.56)	(46.11)
MPA	70/59		0.82	0.78	0.81	0.86	1.01
MPA	75/63		0.86	0.83	0.87	0.91	1.07
MPA	80/67		0.93	0.89	0.91	0.96	1.12




Heating Chart:

°F (°C)	ODT		57/53	47/43	37/33	27/23	17/13
	IDT		(13.89/11.67)	(8.33/6.11)	(2.78/0.56)	(-2.78/-5)	(-8.33/-10.56)
BAR	55		30.3	28.5	25.3	22.8	20.8
BAR	65		32.5	30.0	26.6	25.4	23.3
BAR	75		33.8	31.5	27.8	26.3	24.9

°F (°C)	ODT		57/53	47/43	37/33	27/23	17/13
	IDT		(13.89/11.67)	(8.33/6.11)	(2.78/0.56)	(-2.78/-5)	(-8.33/-10.56)
PSI	55		439	413	367	330	302
PSI	65		471	435	386	368	339
PSI	75		489	457	403	381	362

°F (°C)	ODT		57/53	47/43	37/33	27/23	17/13
	IDT		(13.89/11.67)	(8.33/6.11)	(2.78/0.56)	(-2.78/-5)	(-8.33/-10.56)
MPA	55		3.03	2.85	2.53	2.28	2.08
MPA	65		3.25	3.00	2.66	2.54	2.33
MPA	75		3.38	3.15	2.78	2.63	2.49



10. Exploded Component Views:

Please refer to the separate document available covering the Exploded Component Views for this product line.