

WYS/RYB/CYB/UYB

Make sure you are connected to a 2.4GHZ internet Wi-Fi with no VPNs active!

Apple: [Click here to go to the iOS App Store to download NETHOME PLUS](#)

Android: [Click here to go to the Google Play Store to download NETHOME PLUS](#)

WYS Wall: [Click Here to Buy the USB Accessory](#)

CYB/RYB/UYB Ceiling: [Click Here to Buy the Wired Wall Thermostat Accessory](#)

>> This installs on the indoor board; plug CN40 (See Figure 4 below.)

First you must download the NETHOME PLUS app from the store and enter the setup phase in the app where it asks you to reset the system. Once you have done so, please do the following:

1. Install the accessory, the USB device goes on the underside of the display panel.
2. Turn off the unit using the remote control.
3. Turn the circuit breaker that is powering the outside unit off for 10 seconds, then turn it back on.
4. Turn on the unit using the remote control.



5. Press the “DISPLAY” button on the remote control 6 times in a row within 6 seconds.

[If your remote says RG10A4 on the back, push the “SET” button until the top right corner shows the Wi-Fi symbol] (See Figures 1-3 below.)

5. The indoor unit will flash “AP” or “CF” on the LED display.

6. The unit is ready to pair.

You can SKIP the part where it asks for a reset on the app.

7. The unit will be paired, and you can repeat these steps for any other units.



Figure 1 - RG10A, the “SET” button on the left side.




Figure 2 - RG10 screen, note the symbols on the top right corner.




Figure 3 - model number RG10 label on the back of the new remote



Figure 4 - CN40 on ceiling units (4-pin connector) for the wired thermostats.